



MOUNTING INSTRUCTION BPW axle bracket caravan

E&P hydraulics has designed some **BPW caravan mounting brackets** (\emptyset 70 - \emptyset 84 en \emptyset 92 mm.) These mountingbrackets are in use for mounting the two hydraulic axle supports to a **round axle**. To keep the hydraulic jacks in place on these round axle, some extra mounting parts are included to **prevent twisting**.

See below for the correct assembly of these components (A, B, C en D).







